




Cejipac Sdn. Bhd.

Container Loading & Securing Plan For 25-kg Bags

1.0 Plan



Top View

Door View

2.0 Method for 20-footer

1. Ensure that all the 25-kg bags are touching each other and the container walls during loading .Start from the closed end of the container . It is recommended to use the interlocking method for stacking the bags.
2. At the middle of the container place allow space in the middle to place and inflate one 90 x 220cm dunnage bag(DB) placed vertically .
3. Sandwich the dunnage bag between two pieces of used cardboard to prevent puncture by sharp protrusion and to distribute the pressure evenly.
4. Place the dunnage bag about 10 cm above the floor or adjust till the the uppermost layer of bags are all touching the DB (the DB will be about 10 cm above the the uppermost layer of bags).
5. Inflate the DB till the bags beside the DB are very tightly wedged against each other and against the container walls(you cannot move any of them with your hands) or you just hear the container wall about to buckle .
6. Continue to load and stack the bags till you come to the container door. Place the bag per Para 4 and at the same time protrude outwards by about 5 cm from last row of bags.
7. Inflate the DB till all the bags are wedged by the DB and container walls are tightly secured. Plug the valve and close the container doors.
8. It is recommended to use 2 DBs per 20-footer.

3.0 Method for 40-footer

- 3.1 Use the same pattern as for the 20-footer twice i.e 4 DBs.